

TOUCH SWITCH FOR CHIPBOARD

10.05.10 /Touch dimmable switch for chipboard 10-25/Berührungsschalter für Holz 10-25 /
выключатель э/м для плит 10-25

Senzor cu atingere pentru PAL 10-25

