





Cutie distribuitor/colector-repartitor cu capac

Cod	latime[m m]	latimea interiorului [mm]	inaltime [mm]	adancime [mm]
SZP-0	380	335	575-665	110-175*
SZP-1	480	435		
SZP-2	610	565		
SZP-3	760	715		
SZP-4	840	795		
SZP-5	1010	965		
SZP-6	1100	1085		

	R	R+GM	R + GM1F	R + GM2F
	numarul maxim de circuite distribuitor/colector			numarul maxim de circuite cu doi distribuitori/colectori
				
SZP-0	2	-	-	-
SZP-1	5	2	2	-
SZP-2	8	5	4	-
SZP-3	10	8	7	6
SZP-4	12	10	8	8
SZP-5	15	13	12	11
SZP-6	18	15	14	14

Daca nu sunt prevazute in furnitura cu cheita pentru actionarea incuietorii, cutiile pentru distribuitori/colectori se pot desface foarte usor cu surubelnita.