



Pure Freude
an Wasser



23 810 000 **START CLASSIC EINHAND-WASCHTISCHBATTERIE, 1/2"**
S-SIZE



23 810 000 **START CLASSIC EINHAND-WASCHTISCHBATTERIE, 1/2"**
S-SIZE



ERSATZTEILE, November 2016 – now

- 1: Hebel (Order-nr. 46761000)
- 2: Befestigungsring (Order-nr. 46715000)
- 3: Kartusche (Order-nr. 46580000)
- 4: Zugstange (Order-nr. 06329000)
- 5: Mousseur (Order-nr. 48159000)
- 6: Gegenverschraubung (Order-nr. 46249000)
- 7: Ablaufgarnitur 1 1/4" (Order-nr. 28910000)
- 7.1: Stopfen (Order-nr. 07182000)
- 7.2: Exzenterstange (Order-nr. 07052000)
- 8: Exzenterstange (Order-nr. 07341000)*
- 9: Montageschlüssel (Order-nr. 19017000)*

* Optional accessories